

AIRLINK WALL TEMPERATURE SENSOR





DESCRIPTION

This indoor wall mount temperature sensor is used when an AirLink Controller is installed with Constant Diffusers.


Features

- Up to four temperature sensors can be used per AirLink Controller with Constant Diffusers installed.
- Temperature control range from -25 to 40°C.
- IP30 Protection Class.

Wiring Diagram



DIMENSIONS



Model Number	Dimensions, mm		
	A	B	C
DCV-TEMP-TMWM	75	60	25